



## Table of content

Safety instructions.....	3
Unpacking.....	3
Requirements for the installation location .....	4
Slicing.....	4
Food holder .....	4
Cleaning.....	4
Removing the blade.....	4
Carriage guide .....	5
Customer service department .....	5

## Safety instructions

This unit complies with the statutory safety regulations. Improper use can, however, lead to personal injury and property damage.

To handle the unit safely, follow the instructions below:

- Repairs are only allowed to be performed by a specialist or by the Graef customer service department. Improper repairs can lead to extreme hazards for the user. Furthermore, the warranty claim expires.
- Only Graef customer service is authorised to repair the unit during the warranty period, otherwise the warranty expires for subsequent damages.
- Defective components must be replaced solely with genuine spare parts. Fulfilment of the safety regulations is only guaranteed if these parts are used.
- This unit may not be used by children.
- Children should be supervised to ensure that they do not play with the unit.
- This unit is intended to be used in household

and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.

- This unit must be used with the carriage and food holder unless the size and shape of the items to be sliced do not permit its usage.
- Do not use the packing material as a toy. Danger of suffocation.
- Do not use the packing material as a toy. Danger of suffocation.
- Do not use any aggressive or abrasive cleaning agents and do not use any solvents.
- Do not scratch off stubborn soiling with hard objects.

## Unpacking

To unpack the unit, proceed as below:

- Take the unit out of the carton.
- Remove all pieces of the packing.
- Remove any possibly extant labels on the manual universal slicing machine (do not remove the rating plate).

## **Requirements for the installation location**

For safe and flawless operation of the unit, the place of location must meet these prerequisites:

- The unit must be set up on a firm, flat, level, and non-slip base that has sufficient load bearing capacity.
- Select the place of location so that children cannot reach the sharp blade in the unit.

## **Slicing**

- Place the carriage on the carriage guide profile.
- Place the items to be sliced on the carriage.
- Set the desired slicing thickness.
- Turn the handle away from your body and push the items to be sliced to the front.
- Soft items to be sliced (e.g., cheese or ham) can be sliced best when cool.
- Soft items can be sliced better when you turn faster and push the items to be sliced forward more slowly.
- To slice vegetables, it is sufficient to turn slowly, partially even only scraping while the blade is stationary.
- When slicing cucumbers or carrots, it is advan-

tageous if they are cut to a uniform length beforehand.

## **Food holder**

- The unit must not be used without the food holder unless the size and shape of the items to be sliced do not permit its use.
- As soon as it is no longer possible to correctly hold onto the items to be sliced, the food holder must be used.
- Place the food rests or the small items for slicing on the carriage.
- Set the food holder on the rear of the carriage and put the food holder onto the items to be sliced.
- Proceed as above as described in "Slicing".

## **Cleaning**

- Clean the exterior of the unit with a soft, moist cloth. If heavily soiled, a mild detergent can be used.

## **Removing the blade**

Please occasionally unscrew the blade and clean the interior of the unit. Handle the blade with great care! Caution: sharp blade.

- Remove the carriage.
- Turn the blade, e.g. using a coin.
- Clean the blade with a moist cloth.
- Subsequently clean the blade with a dry cloth.
- Grease the gear.
- Replace the blade and tighten it firmly.
- Periodically grease the gears.

### **Carriage guide**

Periodically grease the carriage guide.

- Remove the carriage.
- Turn the carriage over.
- Grease the carriage guide with a bit of acid-free sewing machine oil.
- Replace the carriage.

### **Customer service department**

If your Graef unit becomes damaged, please contact your dealer or the Graef customer service department.